# QUICK INSTALLATION GUIDE

# **Super Premium Built-in Bottom Mount Refrigerators**



# STEP 1

#### Allow Refrigerator to Rest Before Use

- Wait **24 hours** before turning on the refrigerator.
- This ensures the compressor oil settles properly, especially if the unit was transported lying down or at an angle.
- Important: Skipping this step may damage the compressor and affect cooling performance.

# STEP 2

#### Install the Anti-Tilt Bracket

(see installation manual: pages 4, 6 and 18)

 Mount the anti-tilt bracket securely to prevent the refrigerator from tipping.

# STEP 3

### **Leveling and Door Alignment**

(see installation manual: page 9)

- Ensure all leveling feet are properly adjusted to stabilize the refrigerator.
- Accurate leveling is critical for preventing operational issues and ensuring proper door alignment.

# STEP 4

# Align the Custom Panel

(see installation manual: pages 10 to 17)

- Custom panel weight can affect door sealing.
- Use the adjustment points provided to align the panel and ensure a proper seal. If the product is installed to the incorrect depth within the cabinet niche, the door will not make an effective seal or may not open properly.





Français

Español

### STEP 5

#### Handle Installation (If Applicable)

- Install the handle kit, making sure to apply the provided Loctite thread locker during installation to prevent loosening over time.
- Refer to the handle installation instructions included in the kit:

For Stainless Steel Panels: Follow the specific guidelines.

**For Wood Panels:** Use threaded inserts for wood. For multiple installations, ensure correct handle alignment.

### STEP 6

#### **Inspect Water Line Connections**

(see installation manual: pages 8, 9 and 20)

- After connecting the water line, inspect all connectors and hoses for leaks.
- Perform this step before sliding the refrigerator into its niche or securing it to adjacent cabinetry.
- Important: Fix leaks immediately to avoid damage to floors or cabinets.

### STEP 7

#### **Activate the Ice Maker (If Applicable)**

(see installation manual: page 20)

• After installation, turn on the ice maker to enable ice production.

# STEP 8

# Install the Water Filter (If Applicable)

(see user manual: page 34)

- Before turning on the automatic ice maker, ensure that the water filter cartridge is installed. Replace the filter regularly as indicated in the user manual.
- If the water supply is already filtered through a centralized system, the cooling unit can be set in water filter bypass mode by removing the filter cartridge.